



# DSS Professional Quick Start Guide


Ver: 7.00.000

# Content

<b>1 Configuration Flow Chart .....</b>	<b>1</b>
<b>2 Pre-installation Preparation .....</b>	<b>2</b>
2.1 Configure the IP address of sever .....	2
2.2 Configure the system time of server .....	3
<b>3 Install &amp; Start DSS Professional .....</b>	<b>7</b>
3.1 Hardware Requirement of DSS Sever .....	7
3.2 Installation .....	7
<b>4 Add User .....</b>	<b>11</b>
<b>5 Add Encoder.....</b>	<b>15</b>
5.1 Add Manually .....	15
5.2 Add Encoder by Auto Search.....	18
<b>6 Download and Install the Client.....</b>	<b>20</b>
6.1 Hardware Requirement for PC .....	20
6.2 Installation .....	20
<b>7 Live View .....</b>	<b>22</b>
7.1 Organization Operation.....	22
7.2 Device Preview .....	22
7.3 Channel Preview .....	24
7.4 Display live Video .....	25

# 1 Configuration Flow Chart

Configuration flow chart as follow:



# 2 Pre-installation Preparation

## 2.1 Configure the IP address of sever

Step 1. Use Gigabit cable to connect to server and switch

Step 2. Click the “start” button, Select the “Network”, as shown in Figure 2-1




Figure2-1 Select the “Network”

Step 3. Select the “Change adapter settings” on the pop-up page, as shown in Figure 2-2




Figure 2-2 Select “Change adapter settings”

Step 4. Set the IP information(TCP/IPv4) on the pop-up page shows in Figure 2-3




Figure 2-3 Config the IP

## 2.2 Configure the system time of server

Step 1. Click the “time display” on the bottom right of the desktop, the pop-up page shows in Figure 2-4




Figure 2-4 Set the system time

Step 2. Click “Change date and time settings”, the pop-up page shows in figure 2-5. Click “Change time zone” to change the time zone.




Figure 2-5 Change the time zone

Step 3. Choose the time zone and set “Automatically adjust clock for Daylight Saving Time”. As shown in Figure 2-6




Figure 2-6 Set the time zone

Step 4. Click  to save the setting.

Step 5. Click “Change date and time” in the page show in Figure 2-7.




Figure 2-7 Choose “Change the data and time”

Step 6. Setting time and data, as shown in Figure 2-8





Figure 2-8 Set time and data

Step 7. Click  to save the setting of data and time.



# 3 Install & Start DSS Professional


## 3.1 Hardware Requirement of DSS Sever


Hardware requirement as follow:

Table 3-1 Hardware requirement

Hardware requirement of DSS Server	
Recommend	CPU: E5-2640 v3@2.60GHz 2.60GHz 8core RAM: 16GB Ethernet port: 1Gps System Disk: 1TB, 500G free for DSS.
Low-end	CPU: E3-1220 v5 @3.00GHz 3.00GHz 4core RAM: 8GB Ethernet port: 1Gps System Disk: 1TB, 500G free for DSS.

## 3.2 Installation



Step 1. Double click  to enter installation mode, see Figure 3-1.

**Note:** We can get the version and date of this package from the file name. Please check if the package is you want.




Figure 3-1 Start installation

Step 2. Check I have read and agree the agreement, click Next.

Step 3. Select installation path, and you can use the default path, or customize path. After you select path, it will show space required to install and available space in the selected path, see 错误!未找到引用源。 .




Figure 3-1 Choose the installation path

**Note:**

- After selecting the appropriate directory, it will show the space required for the installation and the available space for the selected path.
- If “Install” button is grey, please check if installation path is correct, or if space available in installation path is enough.

Step 4. Customize installation path, click Install to start installation, see 错误!未找到引用源。 and 错误!未找到引用源。 .




Figure 3-3 Change the installation path




Figure 3-4 Install

Step 5. It shows progress bar of installation and this takes about 3-5 minutes, please wait.




Figure 3-5 Installation progress

Step 6. Installation is complete, click Start New to enable DSS Pro, see Figure 3-6.





Figure 3-6 Completed installation

Step 7. Click DSS Server shortcut icon  to check server status which is normally running.

# 4 Add User

We can quickly add user assign the default role “system” and “Administrator”. The operation is as follows:

Step 1. Input the IP address of DSS Server in the browser (IE, Chrome, Firefox) to enter the web manager, see figure 4-1




Figure 4-1 Login page

Step 2. Enter username and password, default is system and 123456 respectively. For the homepage pops up after logging in. See Figure 4-2.

**Note:**

- When logging in with the initial password, a dialogue box for changing the password will pop up. In order to continue logging in, users must change the initial password.
- If it's your first-time logging into the DSS system, then please add this IP to the trust list.




Figure 4-2 Homepage

- In order to change the password or log out, click username on the right upper corner.
- Quick entry of commonly used modules are displayed on the interface. To display all functional modules or open a new one, click the **+** on the right of the Home button.
- Overview: For displaying the online/offline status of devices, users, services, etc., as well as the occupied space on the hard discs.
- Authorization: To view the authorization details, and purchase the license file by following related procedures if necessary.
- Help: To view the user guide, operation manual for mobile clients, FAQ files, etc.

Step 3. Click **+** on the homepage, then we can enter the Navigation page, see figure 4-3




Figure 4-3 Navigation page

Step 4. Click the “User” on the Navigation page, it will go to the following page see figure 4-4




Figure 4-4 User page

Step 5. Click **+ Add**. An “Add User” dialogue box will pop up.

Step 6. Configure “User Name”, “Password”, “Confirm Password”, “Expiry(Days)”, “Email Address”, “PTZ Control Permission” and so on. Check the roles below, then device rights and control rights of the corresponding roles will display on the right. The system will display the interface as shown in Figure 4-5

Figure 4-5 Add User

**Note**

- If no role is selected, then the user has no “Device Rights” or “Control Rights”.
- You can select multiple roles at a time.

Step 4. Click “OK” to add the user.

Click to freeze the user, then the user will be signed out from the client.

Click to change user information other than username/password.

Click to delete the user.



# 5 Add Encoder

## 5.1 Add Manually

Before using various functions of the Client, add organizations and devices from the Manager. Enter IP address of the DSS platform in IE address bar, to login to the DSS Manager. Detailed steps to be followed:

Step 1. Click **+** on the right side of the “Home” button. All functional blocks will be displayed on the interface, as shown in Figure 5–1.




Figure 5–1 Navigation page

Step 2. Click “Device”.

Step 2. Device management interface will be displayed, as shown in Figure 5–2.

IP Address	Type	Port
172.10.1.30	DVR	37777
172.10.1.34	NVR	37734
172.10.1.40	Unknown	37777
172.10.1.62	NVD	37777

Encode	IP Address	Device Name	Type	Org	Status	Offline Cause	Operation
1000010	172.10.3.102	MDVR102	MDVR	root	Offline	Main connection failed.	✎ ✕
1000005	172.10.1.123	172.10.1.123	DVR	root	Offline	Main connection failed.	✎ ✕
1000002	172.10.3.66	172.10.3.66	SmartIPC	ipc IPC112abc杭州	Offline	Main connection failed.	✎ ✕
1000035	10.33.10.27	10.33.10.27	DVR	root	Online		⚙ ✎ ✕
1000033	10.33.10.135	moniqi-ns	IPC	root	Online		⚙ ✎ ✕

Figure 5-2 Device

Step 3. Click **+ Add** .A dialogue box of “Add All” pops up, see Figure 5-3.

**Add All** ✕

**1. Login Information.** 1.Login Information 2.Device Information

Adding Protocols:

Manufacturer:

Add Type:

Device Category:

IP Address:

Device Port:

Username:

Password:

Org:

Video Server:

Figure 5-3 Add encoder

Step 4. Select “Adding Protocols”, “Manufacturer”, “Add Type”, “Device Category”, “Org” and “Video Server”, and input “IP Address”, “Device Port” and “Username/Password”, then click “Add”. System will automatically get the encoder information, as in Figure 12-4.

Figure 5-4 Add Encoder

Table 5-1 Add Device Info

Parameter	Note
Add Type	<p>Ways to add devices. Parameters and descriptions:</p> <ul style="list-style-type: none"> <li>● IP Address: If a device has static a IP, then users can add it by adding the IP.</li> <li>● IP Segment: For a number of devices with successive IPs (for example, 192.168.1.50 to 192.168.1.100), if, excluding IP, all the other parameters (e.g., Device Port, Channel Amount and Org) of these devices are the same, then you can batch adding these devices by entering the start IP and end IP.</li> <li>● Domain Name: Add device by adding the domain name. As the domain name of a device is unique, you can add a device via adding its domain name when the IP of the device is unknown.</li> <li>● Auto Register: If a device has dynamic IP or it's in LAN, “Auto Register” is needed to add it in the DSS device list. For example, add on-board equipment by auto register.</li> <li>● ONVIF: For device supportive of ONVIF protocol, add the device via ONVIF.</li> </ul>
Video Server	<p>Server to which the video belongs.</p> <p>Click text box to select corresponding center server or distribution unit from the dropdown list.</p>
Device type	<p>Device types supported by the system include: DVR, IPC, NVS, MDVR, NVR, Smart NVR, MPT300, EVS, Smart IPC, VTT and Thermal Camera.</p>
Zero Channel Coding	<p>Mix multiple windows into one channel for transmission.</p>

Step 5. Choose “Device Type” and input “Device Name”, “Video Channel”, “Alarm Input / Output Channel”, etc.

Step 6. Click “OK”. If you want to continue adding devices, click “Add More”.

When adding device completed, the interface is shown as Figure 5–5.

+ Add		Delete		Search				
All	Encoder	Decoder						
<input type="checkbox"/>	Encode	IP Address	Device Name	Type	Org	Status	Offline Cause	Operation
<input type="checkbox"/>	1000006	5.1.5.1	NVD1	NVD	NewGroup1	Offline	Main connection failed.	
<input type="checkbox"/>	1000004	1.2.3.1	1	DVR	root	Offline	Main connection failed.	
<input type="checkbox"/>	1000005		autoDVR	DVR	NewGroup1	Online		
<input type="checkbox"/>	1000003	172.10.1.201	37779	DVR	root	Online		
<input type="checkbox"/>	1000002	172.10.1.201	37778	DVR	root	Online		

Figure 5-5 Adding Completed

## 5.2 Add Encoder by Auto Search

“Auto Search” can be used to add device when channel of the device is in the same LAN as the platform server. Steps to add Encoder by Auto Search as follow:

Step 1. Click **Pack Down** in the upper part of “Device Management” interface. System will automatically search devices. See Figure 5–6 for the search results.

+ Add		Refresh		Device Network					Pack Up
<input type="checkbox"/>	IP Address	Type							
<input type="checkbox"/>	172.10.0.111	Unknown							37777
<input type="checkbox"/>	172.10.1.27	EVS							37777
<input type="checkbox"/>	172.10.1.30	DVR							37777
<input type="checkbox"/>	172.10.1.33	NVR							37777


+ Add		Delete		Search				
All	Encoder	Decoder						
<input type="checkbox"/>	Encode	IP Address	Device Name	Type	Org	Status	Offline Cause	Operation
<input type="checkbox"/>	1000006	5.1.5.1	NVD1	NVD	NewGroup1	Offline	Main connection failed.	
<input type="checkbox"/>	1000004	1.2.3.1	1	DVR	root	Offline	Main connection failed.	
<input type="checkbox"/>	1000005		autoDVR	DVR	NewGroup1	Online		


Figure 5-6 Search Results

Step 2. You can reconfigure IP by clicking **Device Network**, or click **Refresh** to search devices of IP within the range.

**Note:**

Devices on the same network segment are to be searched by default.

Step 3. Check devices to be added, and click . A dialogue box “Batch Add” pops up. See Figure 5–7.



The image shows a dialog box titled "Batch Add" with a close button (X) in the top right corner. It contains four input fields: "Org:" with a dropdown menu showing "root"; "Video Server:" with a dropdown menu showing "Center Server"; "Username:" with a text input field containing "admin" and a red asterisk to its left; and "Password:" with a text input field containing six dots. At the bottom right, there are two buttons: "OK" (blue) and "Cancel" (grey).

Figure5-7 Batch Add

Step 4. Select “Org” and “Video Server” from the dropdown list, and input “Username” and “Password”.

**Note:** “Username” and “Password” are username and password to login to device, default values being both “admin”.

Step 5. Click “OK”. System will add device into corresponding organization.

# 6 Download and Install the Client

## 6.1 Hardware Requirement for PC

To install the DSS Client, the PC must meet the requirements as shown in Table 10-1.

Table 6-1 Hardware Requirement for PC

Requirement of DSS Control Client	
Recommend	CPU: Intel Core i5, 64 bits 4 Core Processor Memory@8GB Graphics Card: NVIDIA® GeForce®GT 730 Ethernet port@1000Mbps Hard Drive Capacity: 200G free for DSS Control Client
Low-end	CPU: Intel Core i3, 64 bits 4 Core Processor Memory@4GB Graphics Card: Intel® HD Graphics 4400 Ethernet port@1000Mbps Hard Drive Capacity: 100G free for DSS Control Client

## 6.2 Installation

Steps to install the DSS Client:

Step 1. Download and install the software.

1. Input IP address of DSS in IE. The login interface of the DSS Manager will be displayed as shown in Figure 6-1.





Figure 6-1 Login page

2. Click  to download the C/S Client. System pops up the “File Downloads” dialogue box.
3. Click “Save” to download and save the DSS client software on the PC.

Step 2. Install the client program and check “start now”, as shown in Figure 6-2.




Figure 6-2 Installation Finished

# 7 Live View

Login to DSS Client and “Preview” interface will be displayed by default.

## 7.1 Organization Operation

Device Tree on the left side counts number of total devices and online devices by category of organization. See Figure 7-1.




Figure 7-1 Device Tree

Right click Organization, as shown in Figure 7-1.




Figure 7-2 Right click

- Video Tour can be enabled by right-click, with Tour intervals selected from 10s, 30s, 1min, 2min, 5min and 10min.
- Device Tree is supported to display by name or by IP.
- Device Tree is supported to display in an ascending, descending, or default order.
- Right click to hide offline node.

## 7.2 Device Preview

From “Local Config > General”, check “Device Tree display model”. See Figure 7–3. Then Device Tree in the Preview interface shows devices and channels, as in Figure 7–4.






Figure7-3 Device tree display model




Figure 7-4 Device display type

Right click device, as shown in Figure 7-5.




Figure 7-5 Right Click

Video Tour can be enabled here by right-click, with Tour intervals selected from 10s, 30s, 1min, 2min, 5min and 10min.

### 7.3 Channel Preview

Uncheck “Device Tree display model” from “Local Config > General”, then device tree in the preview interface will be displayed by channel. See Figure 7-6.




Figure 7-6 Display by Channel

Right click Channel to add it to the favorite.

## 7.4 Display live Video

Step 1. Choose channel from the device list on the left side of the “Preview” interface, and double click, or drag it to video window. If you double click device, then all channels of the device will be opened. Real time monitoring interface is displayed in the video window, as in Figure 7-7.






Figure 7-7 Live

Serial Number	Parameter	Note
1	Bit Stream and Quick Start	<ul style="list-style-type: none"> <li>Here displays encoding format, bit stream info and quick-start buttons. Description for quick-start buttons:                             <ul style="list-style-type: none"> <li>: Turn on/off Instant Playback, playback time can be set in “Local Config”. There shall be center record or device record for instant playback as precondition, center record be played back with priority.</li> <li>: Turn on/off Audio.</li> <li>: Turn on/off Device Audio Talk. Check “Self-adaptive Audio Talk Parameters” from “Local Config &gt; General”; when audio talk is on, it will automatically adapt to various parameters without showing a pop-up box.</li> <li>: Turn on/off Local Record.</li> <li>: Launch Snapshot.</li> </ul> </li> </ul>
2	Favorite and Device Tree Search	<ul style="list-style-type: none"> <li>Search is supported by input device name or channel name in  here.</li> <li>: Add, Delete or Rename Favorite. Favorite Tour supported.</li> </ul>
3	Map Resource	<ul style="list-style-type: none"> <li>Map can be opened in preview window, both GIS map and Raster</li> </ul>

Serial Number	Parameter	Note
		map.
4	View	<ul style="list-style-type: none"> <li>Live video window can be saved as View. Three-level directory is adopted for view, with level one as root node, level two for group and level three for view. Video Tour is supported from root node and group node, with tour intervals selected from 10s, 30s, 1min, 2min, 5min and 10min. Maximum of 100 views can be created.</li> </ul>
5	PTZ	<ul style="list-style-type: none"> <li>More info about PTZ of Speed Dome, see “错误!未找到引用源。 错误!未找到引用源。”.</li> </ul>
6		<ul style="list-style-type: none"> <li>Live video can be saved as view.</li> </ul>
7	Aspect Ratio	<ul style="list-style-type: none"> <li>Aspect ratio of the video window, selected from two modes for video play: actual scale and fit in window.</li> </ul>
8	Window Split Mode	<ul style="list-style-type: none"> <li>Select from modes among 1 to 64 to set window split mode, or click  to define split mode.</li> </ul>
9	Full Screen	<ul style="list-style-type: none"> <li>Switch the video window to “full screen” mode. To exit “full screen”, press the Esc key, or right click to select “exit full screen”.</li> </ul>

Step 2. To configure active video window, right click preview window. See Figure 7–8.









Figure 12–17 Right-click Menu

Parameter	Note
Close Video	<ul style="list-style-type: none"> <li>Close active video window.</li> </ul>
Close All Videos	<ul style="list-style-type: none"> <li>Close all video windows.</li> </ul>
Audio Enable	<ul style="list-style-type: none"> <li>Same as , to enable or disable camera audio.</li> </ul>
Audio Talk Enable	<ul style="list-style-type: none"> <li>Same as , to enable or disable audio talk of corresponding device. Check “Self-adaptive Audio Talk Parameters” from “Local Config &gt; General”; when audio talk is on, it will automatically adapt to various</li> </ul>

Parameter	Note
	parameters without showing a pop-up box.
Start Local Record	Same as  , to record audio/video of the active video window and save them in local PC.
Snapshot	<ul style="list-style-type: none"> <li>Same as , to save image of the active video window as picture (one picture for each snapshot).</li> </ul>
Continuous Snapshot	<ul style="list-style-type: none"> <li>To save image of the active video window as picture (three snapshots each time by default).</li> </ul>
Set Alarm Window	<ul style="list-style-type: none"> <li>Turn on/off alarm output.</li> </ul>
Switch Bit Stream	Switch among “Main stream”, “Sub stream” and “Third stream”.  Note If selecting “Sub stream” or “Third stream”, you need to check “enable Sub Stream” and “enable Third Stream” in the “Bit Stream” dropdown list when adding encoder from the Manager.
Play Mode	<ul style="list-style-type: none"> <li>Switch between the modes of “Real Time Priority”, “Fluency Priority”, “Balance Priority” and custom defined mode.</li> </ul>
Video Adjustment	<ul style="list-style-type: none"> <li>Perform video adjustment and video enhancement.</li> </ul>
Screen Mode	<ul style="list-style-type: none"> <li>Three modes supported: Standard mode, 1+3 mode and 1+5 mode.</li> </ul>
Fisheye Installation Mode	<ul style="list-style-type: none"> <li>Supporting wall mount, in-ceiling mount and ground mount.</li> </ul>
Fisheye View	For different fisheye installation modes, there are different views: Panoramic View: 360-degree panoramic view Double Panoramic View: Two 180-degree panoramic views Four Splits: Split the whole window into 4 parts in vertical and horizontal direction, allowing direction adjustment for each part separately Single Window: only one single window
Add To Favorite	<ul style="list-style-type: none"> <li>You can add the active channel or all channels into Favorite.</li> </ul>
Full Screen	<ul style="list-style-type: none"> <li>Switch the video window to “full screen” mode. To exit “full screen”, double click video window, or right click to select “exit full screen”.</li> </ul>
Switch to Playback	<ul style="list-style-type: none"> <li>You can switch between live preview interface and playback interface quickly, without going back to homepage first.</li> </ul>