

---

# **VTO12XX Series User's Manual**

**V1.2.0**

---

## **Welcome**

Thank you for purchasing our product!

This quick start guide is designed to be a reference tool for your system.

Please keep it well for future reference!

---

## Important Safeguards and Warnings

Please read the following safeguards and warnings carefully before using the product in order to avoid damages and losses.

Note:

- Do not expose the device to lampblack, steam or dust. Otherwise it may cause fire or electric shock.
- Do not install the device at position exposed to sunlight or in high temperature. Temperature rise in device may cause fire.
- Do not expose the device to humid environment. Otherwise it may cause fire.
- The device must be installed on solid and flat surface in order to guarantee safety under load and earthquake. Otherwise, it may cause device to fall off or turnover.
- Do not place the device on carpet or quilt.
- Do not block air vent of the device or ventilation around the device. Otherwise, temperature in device will rise and may cause fire.
- Do not place any object on the device.
- Do not disassemble the device without professional instruction.

Warning:

- Please use battery properly to avoid fire, explosion and other dangers.
- Please replace used battery with battery of the same type.
- Do not use power line other than the one specified. Please use it properly. Otherwise, it may cause fire or electric shock.

## Special Announcement

- This manual is for reference only.
- All the designs and software here are subject to change without prior written notice.
- All trademarks and registered trademarks are the properties of their respective owners.
- If there is any uncertainty or controversy, please refer to the final explanation of us.
- Please visit our website for more information.

---

## Table of Contents

1	Product Overview .....	1
1.1	Model List.....	1
1.2	Structure .....	1
1.2.1	VTO1210A-X/VTO1220A .....	1
1.2.2	VTO1210B(W)-X/VTO1220B(W).....	6
1.3	VTO1210C-X.....	10
2	Install VTO .....	14
2.1	VTO1220A/VTO1210A-X .....	14
2.1.1	Screw.....	14
2.1.2	Installation Steps.....	14
2.1.3	Wiring.....	15
2.2	VTO1210B(W)-X/VTO1220B(W).....	15
2.2.1	Screw.....	15
2.2.2	Installation Steps.....	16
2.2.3	Wiring.....	16
2.3	VTO1210C-X.....	17
2.3.1	Screw.....	17
2.3.2	Installation Steps.....	17
2.3.3	Wiring.....	17
3	Debug VTO .....	1
3.1	Digital System .....	1
3.1.1	System.....	1
3.1.2	Configure VTO .....	2
3.1.3	Digital VTH.....	4
3.1.4	Result Test.....	4
3.2	Analog System.....	4
3.2.1	System.....	4
3.2.2	Configure VTO .....	5
3.2.3	Analog VTH.....	7

---

3.2.4.....	8
4 Basic Functions.....	1
4.1 Call.....	1
4.2 Modify Local Config.....	1
4.2.1 Enter Project Settings Interface.....	1
4.2.2 Modify IP, Gateway and Subnet Mask.....	1
4.2.3 Modify Volume Config.....	2
4.3 Issue Card.....	2
4.4 Password Function.....	2
4.4.1 Unlock from VTH and Center .....	2
4.4.2 Unlock from Local .....	2
4.4.3 Unlock via IC card.....	3
4.5 VTO Web Function.....	3
4.5.1 Web Login.....	3
5 Web Function .....	4
5.1 Login.....	4
5.2 System Config.....	4
5.2.1 Local Config.....	5
5.2.2 LAN Config.....	7
5.2.3 Indoor Manager.....	7
5.2.4 Allocator Manager .....	9
5.2.5 Network Config .....	9
5.2.6 Video Set .....	10
5.2.7 Change Password.....	11
5.2.8 User Manage .....	11
5.2.9 IPC Information .....	12
5.2.10 Publish Information .....	12
5.3 Info Search.....	13
5.3.1 Call Record .....	13
5.3.2 Alarm Record.....	14

---

5.3.3	Swiping Card Record .....	14
5.4	Status Statistics.....	15
5.5	Logout.....	15
	Appendix 1 Specifications .....	16

---

# 1 Product Overview

## 1.1 Model List

This manual is designed for multiple product models, please read and check carefully for your product model and its functions.

Product Model	Housing Material	Color	Unlock via IC Card	Keyboard	Control Module
VTO1210A-X	Metal	Metal grey	Support	Numeric keyboard	Built-in
VTO1220A	Metal	Metal grey	Support	Numeric keyboard	Built-in
VTO1210B(W)-X	Fireproof ABS	Black	Support	Touch keyboard	Built-in
VTO1220B(W)	Fireproof ABS	Black	Support	Touch keyboard	Built-in
VTO1210C-X	Metal	Metal grey	Support	Numeric keyboard	Built-in

## 1.2 Structure

### 1.2.1 VTO1210A-X/VTO1220A

#### 1.2.1.1 Front Panel

Plug to power, system boots up and wait for 1 minute, screen turns on. System enters working interface, see Figure 1- 1 VTO1210A-X/VTO1220A.









Figure 1- 1 VTO1210A-X/VTO1220A

Please refer to the following sheet for detailed information.

SN	Name	Function
1	Logo	Decoration logo.
2	Photo Sensor	It can detect the environment light. It is a compensation light option.
3	Compensation Light	It can compensate the camera light in the low illumination environments.
4	Microphone	Audio input



5	Key Panel	<ol style="list-style-type: none"> <li>1.  Button.</li> <li>a) Backspace function. It is to delete the previous symbol.</li> <li>b) Hang up function. It is to hang up the call.</li> <li>2. Number button. Input the number 0 to 9.</li> <li>3.  button. When you are using the password to open the door. Press this button once to begin input. After you input the password, please press it again to complete the operation.</li> <li>4.  Call button. After you input the room number, press it to begin a dial up.</li> <li>5.  Call center button. Press it to call the center directly.</li> </ol>		
6	Speaker	Output audio		
7	Card Induction zone	Use the card to open the door.		
8	LCD	<p>Here you can view prompt information, date, time and etc.</p> <p>Note:</p> <ol style="list-style-type: none"> <li>1. "Call: Room No. + 9</li></ol>	Camera	It is to monitor the video of the door.

### 1.2.1.2 Rear Panel




Figure 1- 2 VTO1210-A-X/VTO1220A

Please refer to the following sheet for detailed information.

SN	Port Name	Function								
1	Network Port	Connect to the RJ45 port.								
2	Access Control Input Port	Connect to signal from the door sensor, door on/off signal. <table border="1" style="margin: 10px auto;"> <tr> <td>Unlock Button</td> <td>GND</td> <td>Door Sensor</td> <td>GND</td> </tr> <tr> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> </table>	Unlock Button	GND	Door Sensor	GND	○	○	○	○
Unlock Button	GND	Door Sensor	GND							
○	○	○	○							
3	Analog Signal Port	Connect to the analog signal of the								

	(VTO1210A-X only)	<p>distributor.</p> <table border="1"> <tr><td>CAN-H</td><td><input type="radio"/></td></tr> <tr><td>CAN-L</td><td><input type="radio"/></td></tr> <tr><td>NA</td><td><input type="radio"/></td></tr> <tr><td>NA</td><td><input type="radio"/></td></tr> <tr><td>Audio +</td><td><input type="radio"/></td></tr> <tr><td>Audio -</td><td><input type="radio"/></td></tr> <tr><td>Video +</td><td><input type="radio"/></td></tr> <tr><td>Video +</td><td><input type="radio"/></td></tr> </table> <p>corresponds</p> <table border="1"> <tr><td>White-blue</td><td><input type="radio"/></td></tr> <tr><td>Blue</td><td><input type="radio"/></td></tr> <tr><td><b>NA</b></td><td><input type="radio"/></td></tr> <tr><td><b>NA</b></td><td><input type="radio"/></td></tr> <tr><td>White-green</td><td><input type="radio"/></td></tr> <tr><td>Green</td><td><input type="radio"/></td></tr> <tr><td>White-brown</td><td><input type="radio"/></td></tr> <tr><td>Brown</td><td><input type="radio"/></td></tr> </table> <p>to</p>	CAN-H	<input type="radio"/>	CAN-L	<input type="radio"/>	NA	<input type="radio"/>	NA	<input type="radio"/>	Audio +	<input type="radio"/>	Audio -	<input type="radio"/>	Video +	<input type="radio"/>	Video +	<input type="radio"/>	White-blue	<input type="radio"/>	Blue	<input type="radio"/>	<b>NA</b>	<input type="radio"/>	<b>NA</b>	<input type="radio"/>	White-green	<input type="radio"/>	Green	<input type="radio"/>	White-brown	<input type="radio"/>	Brown	<input type="radio"/>
CAN-H	<input type="radio"/>																																	
CAN-L	<input type="radio"/>																																	
NA	<input type="radio"/>																																	
NA	<input type="radio"/>																																	
Audio +	<input type="radio"/>																																	
Audio -	<input type="radio"/>																																	
Video +	<input type="radio"/>																																	
Video +	<input type="radio"/>																																	
White-blue	<input type="radio"/>																																	
Blue	<input type="radio"/>																																	
<b>NA</b>	<input type="radio"/>																																	
<b>NA</b>	<input type="radio"/>																																	
White-green	<input type="radio"/>																																	
Green	<input type="radio"/>																																	
White-brown	<input type="radio"/>																																	
Brown	<input type="radio"/>																																	
4	Vandal Proof Alarm Button	It can generate an alarm when there is a vandal operation.																																
5	RS422 Port (Reserved)	<p>Connect to RS422 or RS485 Communication Device.</p> <table border="1"> <tr><td><input type="radio"/></td><td><b>RS485-B</b></td></tr> <tr><td><input type="radio"/></td><td><b>RS485-A</b></td></tr> <tr><td><input type="radio"/></td><td><b>NA</b></td></tr> <tr><td><input type="radio"/></td><td><b>NA</b></td></tr> </table> <p>or</p> <table border="1"> <tr><td><input type="radio"/></td><td><b>Rs422-Rx-B1</b></td></tr> <tr><td><input type="radio"/></td><td><b>Rs422-Rx-B2</b></td></tr> <tr><td><input type="radio"/></td><td><b>Rs422-Tx-A1</b></td></tr> <tr><td><input type="radio"/></td><td><b>Rs422-Tx-A2</b></td></tr> </table>	<input type="radio"/>	<b>RS485-B</b>	<input type="radio"/>	<b>RS485-A</b>	<input type="radio"/>	<b>NA</b>	<input type="radio"/>	<b>NA</b>	<input type="radio"/>	<b>Rs422-Rx-B1</b>	<input type="radio"/>	<b>Rs422-Rx-B2</b>	<input type="radio"/>	<b>Rs422-Tx-A1</b>	<input type="radio"/>	<b>Rs422-Tx-A2</b>																
<input type="radio"/>	<b>RS485-B</b>																																	
<input type="radio"/>	<b>RS485-A</b>																																	
<input type="radio"/>	<b>NA</b>																																	
<input type="radio"/>	<b>NA</b>																																	
<input type="radio"/>	<b>Rs422-Rx-B1</b>																																	
<input type="radio"/>	<b>Rs422-Rx-B2</b>																																	
<input type="radio"/>	<b>Rs422-Tx-A1</b>																																	
<input type="radio"/>	<b>Rs422-Tx-A2</b>																																	
6	Power Port	Connect to 12V DC.																																

7	Access Control Output Port	Control NO/NC of door lock.	
		<input type="radio"/>	<b>NO</b>
		<input type="radio"/>	<b>NC</b>
		<input type="radio"/>	<b>Public</b>
		<input type="radio"/>	<b>GND</b>

## 1.2.2 VTO1210B(W)-X/VTO1220B(W)

### 1.2.2.1 Front Panel

Plug to power, system boots up and wait for 1 minute, screen turns on. System enters working interface, see Figure 1- 3 VTO1210B(W)-X/VTO1220B(W).










Figure 1- 3 VTO1210B(W)-X/VTO1220B(W)

Please refer to the following sheet for detailed information.

SN	Name	Function
1	Logo	Printed logo.
2	Microphone	Audio input
3	Compensation Light	It can compensate the camera light in the low illumination environments.
4	Approaching Induction	It can detect approaching body.
5	Speaker	Output audio

6	Key Panel	<ol style="list-style-type: none"> <li>1. *Button. <ol style="list-style-type: none"> <li>a) Backspace function. It is to delete the previous symbol.</li> <li>b) Hang up function. It is to hang up the call.</li> </ol> </li> <li>2. Number button. Input the number 0 to 9.</li> <li>3. # button. When you are using the password to open the door. Press this button once to begin input. After you input the password, please press it again to complete the operation.</li> <li>4.  Call button. After you input the room number, press it to begin a dial up.</li> <li>5.  Call center button. Press it to call center directly.</li> </ol>
7	Card Induction Zone	Use the card to open the door.
8	LCD	<p>Here you can view prompt information, date, time and etc.</p> <p>Note:</p> <ol style="list-style-type: none"> <li>1. "Call: Room No. +  ". Please input the room number first and then press the button  to dial;</li> <li>2. "Call Center: Press  button". Please press the button  to call center.</li> <li>3. "Password: # + password + #", If you want to open the door via the password, please press the button # and then input the room number and password. Please press the button # to confirm.</li> </ol>
9	Camera	It is to monitor the video of the door.

1.2.2.2 Rear Panel




Figure 1- 4 VTO1210B(W)-X/VTO1220B(W) rear structure

Please refer to the following sheet for detailed information.

SN	Port Name	Function								
1	Vandal Proof Alarm Button	It can generate an alarm when there is a vandal operation.								
2	Network Port	Connect to the RJ45 port.								
3	Access Control Input Port	Connect to signal from the door sensor, door on/off signal. <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>Unlock Button</td> <td>GND</td> <td>Door Sensor</td> <td>GND</td> </tr> <tr> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> </table>	Unlock Button	GND	Door Sensor	GND	○	○	○	○
Unlock Button	GND	Door Sensor	GND							
○	○	○	○							
4	Power Port	Connect to 12V DC power.								
5	Access Control Output Port	Open or close the NO/NC lock.								

		<table border="1"> <tr> <td><input type="radio"/></td> <td><b>NO</b></td> </tr> <tr> <td><input type="radio"/></td> <td><b>NC</b></td> </tr> <tr> <td><input type="radio"/></td> <td><b>Public</b></td> </tr> <tr> <td><input type="radio"/></td> <td><b>GND</b></td> </tr> </table>	<input type="radio"/>	<b>NO</b>	<input type="radio"/>	<b>NC</b>	<input type="radio"/>	<b>Public</b>	<input type="radio"/>	<b>GND</b>								
<input type="radio"/>	<b>NO</b>																	
<input type="radio"/>	<b>NC</b>																	
<input type="radio"/>	<b>Public</b>																	
<input type="radio"/>	<b>GND</b>																	
6	Analog Signal Port	Connect to the analog signal of the distributor.																
7	RS485 Port	<p>Connect to RS422 or RS484 communication device.</p> <table border="1"> <tr> <td><b>Rs485-B</b></td> <td><b>Rs485-A</b></td> <td><b>NA</b></td> <td><b>NA</b></td> </tr> <tr> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> </tr> </table> <p>or</p> <table border="1"> <tr> <td><b>Rs422-Rx-B1</b></td> <td><b>Rs422-Rx-B2</b></td> <td><b>Rs422-Tx-A1</b></td> <td><b>Rs422-Tx-A2</b></td> </tr> <tr> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> <td><input type="radio"/></td> </tr> </table>	<b>Rs485-B</b>	<b>Rs485-A</b>	<b>NA</b>	<b>NA</b>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<b>Rs422-Rx-B1</b>	<b>Rs422-Rx-B2</b>	<b>Rs422-Tx-A1</b>	<b>Rs422-Tx-A2</b>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Rs485-B</b>	<b>Rs485-A</b>	<b>NA</b>	<b>NA</b>															
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>															
<b>Rs422-Rx-B1</b>	<b>Rs422-Rx-B2</b>	<b>Rs422-Tx-A1</b>	<b>Rs422-Tx-A2</b>															
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>															

## 1.3 VTO1210C-X

### 1.3.1.1 Front Panel

Plug to power, system boots up and wait for 1 minute, screen turns on. System enters working interface, see Figure 1- 5 VTO1210C-X.













Figure 1- 5 VTO1210C-X

Please refer to the following sheet for detailed information.

SN	Name	Function
1	Logo	Printed logo.
2	Microphone	Audio input
3	Compensation Light	It can compensate the camera light in the low illumination environments.
4	Speaker	Output audio
5	Key Panel	1. *Button. c) Backspace function. It is to delete the previous symbol. d) Hang up function. It is to hang up the call. 2. Number button. Input the number 0 to 9.

		<p>3. <b>#</b> button. When you are using the password to open the door. Press this button once to begin input. After you input the password, please press it again to complete the operation.</p> <p>4.  Call button. After you input the room number, press it to begin a dial up.</p> <p>5.  Call center button. Press it to call center directly.</p> <p>6.  button: In contacts interface, press these buttons to page up and down. They can be customized for special function.</p>
6	Card Induction Zone	Use the card to open the door.
7	LCD	<p>Here you can view prompt information, date, time and etc.</p> <p>Note:</p> <p>1. "Call: Room No. +  ". Please input the room number first and then press the button  to dial;</p> <p>2."Call Center: Press  button". Please press the button  to call center.</p> <p>3."Password: <b>#</b> + password + <b>#</b>", If you want to open the door via the password, please press the button <b>#</b> and then input the room number and password. Please press the button <b>#</b> to confirm.</p>
8	Camera	It is to monitor the video of the door.

### 1.3.1.2 Rear Panel

VTO1210C-X rear panel is the same with VTO1210B(W)-X/VTO1220B(W), therefore

---

please refer to Ch 1.2.2.2.

---




## 2 Install VTO

Unit VTO on-site installation includes: wall embedded installation, door embedded installation (with box/without box), standalone installation.

This chapter will introduce installation of VTO1220A/VTO1210A-X series, VTO1210B(W)-X/VTO1220B(W) series and VTO1210C-X series.

### 2.1 VTO1220A/VTO1210A-X

#### 2.1.1 Screw

Component	Screw No	Illustration	Quantity
ST3×18 Cross recessed pan head tapping screws –white alloy	Screw a		6
M3×16 Cross slot recessed pan head screws- zinc black	Screw b		1
White expansion pipe $\varnothing$ 6×30mm	None		6

#### 2.1.2 Installation Steps

- Step 1. Fix metal housing on wall with screw a.
- Step 2. Fix device on the metal housing with screw b.






Figure 2- 1

### 2.1.3 Wiring

Please refer to Ch 1.2.1.2.

## 2.2 VTO1210B(W)-X/VTO1220B(W)

### 2.2.1 Screw

Component	Screw No	Illustration	Quantity
ST3×18 Cross recessed pan head tapping screws –white alloy	Screw a		10
M3×16 Cross slot recessed pan head screws- zinc black	Screw b		1

## 2.2.2 Installation Steps

- Step 1. Embed plastic housing into wall.
- Step 2. Fix bracket on the housing with screw a.
- Step 3. Fix device on the bracket with screw b.





Figure 2- 2

## 2.2.3 Wiring

Please refer to Ch 1.2.2.2.

## 2.3 VTO1210C-X

### 2.3.1 Screw

Component	Illustration	Quantity
M4x40 inner hex flower countersunk flat head screws-stainless steel		4

### 2.3.2 Installation Steps

- Step 1. Embed plastic housing into wall.
- Step 2. Fix device on the bracket with screw.




Figure 2- 3

### 2.3.3 Wiring

Please refer to Ch 1.2.3.2.

# 3 Debug VTO

The VTO has digital system and analog system. Please read the following contents before installing system.

Here takes VTO1220A as an example.

## 3.1 Digital System

### 3.1.1 System

See Figure 3- 1 Digital system.




Figure 3- 1 Digital system

Note:

VTO port (dual port VTO refers to Figure 1-4 no. 2 port) connects to IN port on switch. Among switch port 1-6, select any one port to connect to VTH which allows switch to power supply VTH.



### 3.1.2 Configure VTO

Configure VTO info, make sure there is communication among center, VTO and VTH.

Note:

Access VTO WEB config interface via PC, and please make sure PC and VTO both connect to the Internet and are in the same segment.

Step 1. Login WEB.

Via PC remotely access VTO. In Internet Explorer, input IP address of the VTO and enters VTO WEB login page.

You must input username and password in order to login WEB main interface.

Click on login.

Default username: admin

Default password: admin.

Step 2. Set device info.

- a) Select System Config>Local Config.
- b) Set system type to digital (Tcp/IP), video format is WVGA, and set frame rate according to your condition. Click on OK. See Figure 3- 2.




Figure 3- 2

Step 3. Set LAN.

- a) In page, select System Config>LAN Config, enter LAN Config interface.
- b) The default config can ensure VTO and VTH are connected. If you want to configure center, the setup shall match setup in center and check register to the MGT center in LAN Config. See Figure 3- 3.




Figure 3- 3

Step 4. Add digital VTH.

- a) In page, select System Config>VTH Management>Indoor Management.
- b) Click on Add to add VTH.
- c) Click on OK.

See Figure 3- 4.




Figure 3- 4

Note:

- If you want to add many room no., you can modify unit floor and rooms on a floor in Step 2 to batch add room no.
- Parameter with \* are mandatory.

Step 5. Set network info.

- a) In page, select System Config>Network Config.
- b) Set VTO IP address, subnet mask and default gateway. After you are done, WEB page will reboot and go to the new set page. See Figure 3- 5.




Figure 3- 5

### 3.1.3 Digital VTH

Enters digital VTH system settings-project setting, input VTH project password 002236. According to VTO config, input room no.; in network config, set VTH IP, subnet mask, gateway and etc; in network terminal, fill in VTO IP, enable and click on OK.

Note:

Please refer to corresponding VTH user's manual.

### 3.1.4 Result Test

- On VTH, press monitor button to monitor VTH video.
- On VTO, press room no. + ⬆ to call corresponding VTH.

## 3.2 Analog System

### 3.2.1 System

See Figure 3- 6 Analog System.




Figure 3- 6 Analog System

Note:

VTO analog signal port (see Figure 1-2 and 1-4) connects to allocator IN port. Select any port of allocator to connect to VTH which allows allocator to power supply VTH.

A-X connects to analog signal port network cable according to cable color, from down to up are: white-blue, blue, NA, NA, white-green, green, white-brown, and brown.

### 3.2.2 Configure VTO

Configure VTO info, ensure VTO and MGT center, VTO and VTH are connected.

Step 1. Login WEB.

Via PC remotely access VTO. In Internet Explorer, input VTO IP to enter VTO WEB login page. Input account: admin; password: admin. Click on Login

Step 2. Set device info.

- a) In page, select System Config>Local Config.
- b) Set system type to analogue, video format to D1 and set frame rate according to environment. Click on OK. See Figure 3- 7.




Figure 3- 7

**Step 3. Set LAN.**

- a) In page, select System Config>LAN Config, enter LAN Config interface.
- b) The default config can ensure VTO and VTH are connected. If you want to configure center, the setup shall match setup in center and check register to the MGT center in LAN Config. See Figure 3- 8.




Figure 3- 8

**Step 4. Add analog VTH.**

- a) In page select System Config>Indoor Manager>Analog Indoor Manager.
- b) Click on Add to add VTH.
- c) Click on OK.

**Note:**

- If you want to add many room no., you can modify unit floor and rooms on a floor in

Step 2 to batch add room no.

- Parameter with \* are mandatory.

Step 5. Set network info.

- a) In page, select System Config>Network Config.
- b) Set VTO IP address, subnet mask and default gateway. After you are done, WEB page will reboot and go to the new set page. See Figure 3- 9.




Figure 3- 9

Note:

Please refer to Ch 5.

### 3.2.3 Analog VTH

4.3 inch VTH: plug it to power and long press call button, wait until it VTH enters room no. set page. Press SOS button to select digit, and switch number and confirm via call button. Then, VTH will reboot.


7 inch VTH: plug it to power and long press call button, wait until it VTH enters room no. set page. Press SOS button to select digit, and switch number and confirm via call button. Then, VTH will reboot.

Note: For more than one VTH, please set one by one!

For more config, please refer to VTO user's manual.

---




### 3.2.4

- On VTH, press monitor button to monitor VTH video.
- On VTO, press room no. +  to call corresponding VTH.


---

## 4 Basic Functions

### 4.1 Call




Under standby status (Figure 1-1, Figure 1-2), press  or  button, this VTO will call center. The video door phone begins when the port picks up. During the whole process, you can press the button  or \* to end current talk and return to the standby interface.

Under standby status, enter room no. or press  or  to select room no. in contacts, and press  or  to call VTH. The video door phone begins when the VTH picks up.



During the whole process, you can press the button  or \* to end current talk and return to the standby interface.

### 4.2 Modify Local Config

#### 4.2.1 Enter Project Settings Interface

In the standby status, press  or #, input password as 888888 and then press  or # to enter installation setup interface. Select up/down via button 2 and 8, press  or \* to enter sub-interface.

#### 4.2.2 Modify IP, Gateway and Subnet Mask

In project settings --- IP setup interface, select up/down/left/right via button 2,8,4,6, press  or # to enter/exit IP modification status. When you finish, press  or \* to exit modification interface.



---

### 4.2.3 Modify Volume Config

In volume interface, adjust volume via button 4 and 6. When you finish, press **#** or **\*** to exit modification interface.

## 4.3 Issue Card

In card issuing interface, select to issue card with parent card or password via button 2 and 8. Press **#** or **\*** to enter sub-interface.

Issue with parent card: Under issuing card with parent card interface, fill in room no. of the card to be authorized, and swipe it. When it says the card has been authorized successfully, press **#** or **\*** to exit.

Issue with password: Under issuing card with password interface, enter issuing password 002236, press **#** or **#** to enter, fill in room no. of the card to be authorized, and swipe it. When it says the card has been authorized successfully, press **#** or **\*** to exit.

## 4.4 Password Function

### 4.4.1 Unlock from VTH and Center

During calling, talk and monitoring statuses, the center or the VTH can open the door lock of the device remotely. System returns to the standby interface after phone hangs up or the countdown is complete.

### 4.4.2 Unlock from Local

VTO WEB page – A&C Manager—Password Unlock Type, select either uniform password or self password.

Uniform password: In standby interface, press **#** or **#**, input default password: 123456, press **#** or **#** to unlock. Default password can be changed in A&C Manager interface.

---

Self password: n standby interface, press **#** or **#**, input 4-digit room no. + default password: 123456, press **#** or **#** to unlock. For example, to unlock room 101, you shall input: #0101123456#. Default password can be changed in A&C Manager interface.

### **4.4.3 Unlock via IC card**

The door is open after you swipe IC card and the card passed the authentication and station verification.

## **4.5 VTO Web Function**

### **4.5.1 Web Login**

Access VTO from PC, input the IP address of VDP in your explorer to enter the web login page. Input username: admin and password: admin, then you can enter its web page where you can configure the VTO. Please refer to the following chapter for details.

---

## 5 Web Function

### 5.1 Login

In Internet Explorer, input VTO IP address as in Figure 5- 1.



Figure 5- 1

You must input username and password in order to login WEB main interface.

Default username: admin

Default password: admin.

After you login, you will see 4 major settings: system, info search, status statistics, and Logout.

WEB function supports VTO1220A, VTO1220B, VTO1210A-X, VTO1210B(W)-X and VTO1210C-X. WEB pages may be different for different models.

### 5.2 System Config

System Config includes Local Config, LAN Config, Indoor Manager, Network Config, Video Set, Change Password, User Manage, IPC Information, Publish Information.

## 5.2.1 Local Config

### 5.2.1.1 Local Config

In page, select System Config>Local Config. Set parameter, and click on OK. See Figure 5- 2.

Figure 5- 2

Parameter	Note
Device Type	Display device type.
Video Format	Set collected video format by camera, including: WVGA, D1. WVGA resolution is 800×480; D1 resolution is 704×576.
Reboot Date	In set date, device will reboot.
Frame Rate	Set NTSC to 30 and PAL to 25.
Password Unlock Type	Includes self password and uniform password.
Project Password	Password to enter project setting page. Default is 888888.
Unlock Responding Interval	Unlock, after this interval device will respond again. Unit is second.
Door Sensor Check Time	Only use door sensor, check Check Door Sensor Signal Before Lock and set door sensor check time to enable it.
Check Door Sensor Signal Before Lock	When unlock time out, door sensor will alarm.
Unlock Period	Time that door lock remains unlocked. Unit is second.
Issue Card Password	Default is 123456.
FTP IP, FTP port, FTP user, FTP password.	FTP server is used to store picture taken when swipe card at VTO. User can log in FTP to get these pictures.

Menace Password	Set menace password. Default is 654321.
Default Config	Set all parameters to default status. Note: Every half an hour, VTO will automatically saves card no. and VTH info on VTO.

### 5.2.1.2 Config Manager

In page, select System Config>Local Config>Config Manager. See Figure 5- 3.




Figure 5- 3

Paraemter	Note
Restore Backup	Check card info, vth info, and click on Restore Backup to restore default card info and vth info.
Export Config	Export config file ( Config.backup ) .
Import Config	Import config file.
Default All	Device all parameters will be restored to default. <b>Warning:</b> <b>Please back up first before perform this operation.</b>

#### Note:

**Every half an hour, VTO will automatically saves card no. and VTH info on VTO. Therefore, is you want to restore VTH information or card no., please do so within half an hour after these information were changed.**

### 5.2.1.3 System Time

In page, select System Config>Local Config>System Time.

Set date format, time format and system time. Click on OK as complete setup. Or click on Sync PC to make VTO time same as PC time. See Figure 5- 4.




Figure 5- 4

## 5.2.2 LAN Config

In page, select System Config>LAN Config.

Default setting is enough if you just want networking between VTO and VTH, but if you want to set the center, you need to change default settings to be identical with center info. You also need to check box register to MGT center.

If you successfully set center, you may call center by pressing call center button at lower left corner on VTO. See Figure 5- 5.




Figure 5- 5

## 5.2.3 Indoor Manager

Indoor Station Manager mainly includes adding digital/analog VTH, deleting VTH and editing VTH user. VTO1210A-X and VTO1210B-X have digital and analog indoor station

manager. VTO1220A only has digital indoor station manager.

### 5.2.3.1 Add Digital/Analog VTH

Step 1. In page, select System Config>Indoor Manager>Digital Indoor Station (or Analog Indoor Station).

Step 2. Click on Add.

Step 3. Fill in VTH information, click on OK.

See Figure 5- 6 for example as digital VTH.

Figure 5- 6

Note:

Parameters with \* are mandatory.

Parameter	Note	Setup
VTH short no.	VTH short no. is room no., composed of 4 digits of number.	For example, 1101. "11" means floor 11 while "01" means room no. Note: VTH short no. first two digits range is 01~99. Last two digits range is 01~16.
IP Address	Add VTH IP address.	Example: 172.27.0.62.
Short No.	Analog VTH room no.	Example: room no. is 1502, the allocator address is 15, and port no. is 2.
Allocator Address	Allocator dial-up address, range 1~99, write into program and will not be changes in general.	

Allocator Port	Allocator corresponding ports no. 4-ch allocator port is 1~4, 8-ch allocator port is 1~8.	
----------------	---	--

### 5.2.3.2 Modify Digital/Analog VTH

Click on , in pop-up page, modify VTH information.

For digital VTH, you can only modify name information.

For analog VTH, you can only modify name, allocator address and port.

### 5.2.3.3 Delete Digital/Analog VTH

Click on  to delete digital/analog VTH.

## 5.2.4 Allocator Manager

In page, select System Config>Allocator Manager.


You can view allocator ID, MAC address and etc.

## 5.2.5 Network Config

In page, select System Config>Network Config.

Set VTO IP network parameter, you can set VTO IP address, subnet mask and default gateway. After you modify IP address, WEB page will reboot and go to the new set page.

See Figure 5- 7.



<b>System Config</b>		<b>Network Config</b>	
> Local Config		IP Address	10 . 15 . 6 . 145
> LAN Config		Subnet Mask	255 . 255 . 0 . 0
> Indoor Manager		Default Gateway	10 . 15 . 0 . 1
> <b>Network Config</b>		MAC Address	90 - 02 - a9 - 80 - 44 - 64
> Video Set			
> Change Password			
> User Manage			
			Default Refresh OK

Figure 5- 7



## 5.2.6 Video Set

In page, select System Config>Video Set.

When you see “w\_no\_plugins” on screen, please click on it and install control unit according to introduction. See Figure 5- 8.




Figure 5- 8

Parameter	Note
Motion Detection	When detect body approaching VTO, it will automatically turn on indicator.
Brightness, Contrast, HUE and Saturation	Adjust camera video.
Gain Mode	Auto mode: system automatically adjusts.
Scene Mode	Includes: disabled, automatic, sunny and night.
Day/Night Mode	Includes: colorful, automatic, black white.
Backlight Mode	Includes: close, backlight, wide dynamic, and inhibition.
Mirror	Horizontally flip video.
Flip	Vertically flip video.
VTO MIC Volume, VTO Beep Volume	Adjust VTO MIC and beep volume.
Analog MIC Volume, Analog Beep Volume	Adjust analog MIC and beep volume.
Default	Restore all parameter in video set tab to default.
Unlock	Click on unlock to remotely unlock door lock.

---

## 5.2.7 Change Password

In page, select System Config>Change Password.

In Change Password interface, you can change WEB login password of VTO. You must input old password, new password and confirm new password. Click on OK button to save.

## 5.2.8 User Manage

Only when you login as admin, you can add, modify, delete and view user information.


System currently supports two types of user:

- Admin has higher rights to view, edit, delete system configuration right.
- User can only view system configuration.

### 5.2.8.1 Add User

In page, select System Config>User Manage.

Click on Add User, and in pop-up box fill in user info. See Figure 5- 9.




The screenshot shows a dialog box titled "Add User" with a close button in the top right corner. The dialog contains the following fields and controls:

- Username:** A text input field.
- Password:** A password input field with a visibility toggle icon.
- Confirm:** A password input field with a visibility toggle icon.
- User Group:** A dropdown menu currently showing "admin".
- Remark:** A text input field.
- Buttons:** "Save" and "Cancel" buttons at the bottom.


Figure 5- 9

### 5.2.8.2 Modify User

In User Manage interface, click on , system pops up a box, check Change Password. Modify password and remark.

---


### 5.2.8.3 Delete User


In User Manage interface, click on  to delete user.

## 5.2.9 IPC Information

In page, select System Config>IPC Information.

You can view IPC video via the VTH.

In IPC Information interface, click on , system pops up a box, fill in IPC information.  
See Figure 5- 10.



The image shows a 'Modify' dialog box with the following fields and buttons:

IPC Name	<input type="text"/>
IP Address	<input type="text" value="0 . 0 . 0 . 0"/>
Username	<input type="text" value="admin"/>
Password	<input type="password" value="*****"/>
<input type="button" value="OK"/> <input type="button" value="Cancel"/>	

Figure 5- 10

## 5.2.10 Publish Information

In Publish Information page, you can send publish information and view historical information.

### 5.2.10.1 Send Info

In page, select System Config>Publish Information>Send Info.

See Figure 5- 11. Click on Send.





Figure 5- 11

### 5.2.10.2 History Info

In page, select System Config>Publish Information>History Info.

You can view historical information, click on  to delete information.

## 5.3 Info Search

You can view call record, alarm record and swiping card record.

### 5.3.1 Call Record

In page, select Info Search>Call History.

You can search VTO call records and the system can store up to 1124 records.

Click on Export Record to save record to local. See Figure 5- 12.

Index	Call Type	Room No.	Begin Time	Talk Time(m)	End State
1	Outgoing	101	2014-05-14 16:24:14	00:00	Missed
2	Outgoing	101	2014-05-14 16:26:12	00:00	Missed
3	Outgoing	101	2014-05-14 17:24:36	00:00	Missed
4	Outgoing	9901	2014-05-15 11:22:10	00:00	Missed


Figure 5- 12

### 5.3.2 Alarm Record

In page, select Info Search>Alarm Record.

You can search VTO alarm records and the system can store up to 1124 records.

Click on Export Record to save record to local. See Figure 5- 13.



The screenshot shows a web interface with a sidebar on the left containing menu items: System Config, Info Search (with sub-items Call History, Alarm Record, and Swing Card Record), Status Statistics, and Logout. The main area is titled 'Alarm Record' and contains a table with the following data:

Index	Room No.	Event State	Channel	Begin Time
1	9901	Urgency Button	1	2014-05-15 11:23:32
2	9901	Gas Sensor	2	2014-05-15 11:23:32
3	9901	Smoke Sensor	3	2014-05-15 11:23:58
4	9901	Smoke Sensor	3	2014-05-15 11:24:04
5	9901	Urgency Button	1	2014-05-15 11:24:11
6	9901	Gas Sensor	2	2014-05-15 11:24:11

Below the table is an 'Export Record' button. At the bottom right, there are navigation controls including a 'Go to' field and a search icon.


Figure 5- 13

### 5.3.3 Swiping Card Record

In page, select Info Search>Swiping Card Record.

You can search VTO card swiping records and the system can store up to 1124 records.

Click on Export Record to save record to local. See Figure 5- 14.



The screenshot shows a web interface with a sidebar on the left containing menu items: System Config, Info Search (with sub-items Call History, Alarm Record, and Swing Card Record), Status Statistics, and Logout. The main area is titled 'VTO Swing Card' and contains a table with the following data:


Index	Room No.	Card Number	Swing Card Result	Swing Card Time
1	undefined	9db95270	Succ.	2013-07-29 16:57:22
2	undefined	9db95270	Failed	2013-07-29 16:57:27
3	undefined	9db95270	Failed	2013-07-29 16:57:32
4	undefined	9db95270	Succ.	2013-07-29 16:58:03
5	undefined	9db95270	Failed	2013-07-29 16:58:09
6	undefined	9db95270	Failed	2013-07-29 16:58:14
7	undefined	9db95270	Failed	2013-07-29 16:58:14
8	undefined	9db95270	Succ.	2013-07-29 16:58:20
9	undefined	02e57b3d	Failed	2013-09-11 09:54:03

Below the table is an 'Export Record' button. At the bottom right, there are navigation controls including a 'Go to' field and a search icon.

Figure 5- 14

## 5.4 Status Statistics

In page, select Status Statistics>VTH Status.  
You can view connection status of VTH. See Figure 5- 15.



VTH	Status	MON	IP:Port	Reg Time	Off Time
1585	Offline	Unmon	0.0.0.0:0	0	0
9901	Offline	Unmon	0.0.0.0:0	0	0

Figure 5- 15

## 5.5 Logout

Click on Logout. Here you may select either to Reboot Device or Logout system. See Figure 5- 16 and Figure 5- 17.




Figure 5- 16




Figure 5- 17

# Appendix 1 Specifications

Model	VTO1220A	VTO1220B(W)	VTO1210A-X	VTO1210B(W)-X	VTO1210C-X
OS					
Main Processor	Embedded micro processor				
OS	Embedded LINUX OS				
Video					
Video Compression Standard	H.264				
Input/Approaching Induction	1.3 megapixel CMOS camera				
Back Light	Support				
Auto Light Compensation	Support				
Audio					
Input	Microphone				
Output	Built-in speaker				
Bidirectional Talk	Support dual-way bidirectional talk				
Display					
LCD Dimensions	3.5-inch TFT screen		3-inch STN screen	3-inch STN screen	
Resolution	320*240		128*64	128*64	
Operation Mode					
Input	Digital keyboard	Touch keyboard	Digital keyboard	Touch keyboard	Digital keyboard
Card	Built-in IC card induction reader				
Approaching Induction					
Body Approaching	IR, about 1 meter				
Alarm					
Vandal proof	Support				
Access Control					
NO/NC Output	Support				
Door on/off Button	Support				
Door Status Detect	Support				
Network					
Ethernet	10M/100Mbps Self-adaptive				
Network Protocol	TCP/IP				
Storage					
Memory	128MB				
Others					

Power	DC 12V
Power Consumption	Standby≤1W ; work≤10W
Working Environments	-40℃~+60℃
	10~95%RH
Water Proof	VTO1212B(W)-X/VTO1220B Water proof level:IP65; VTO1210A-X/VTO1210C-X Water proof level: IP53



---

**Note:**

- **This manual is for reference only. Slight difference may be found in user interface.**
- **All the designs and software here are subject to change without prior written notice.**
- **All trademarks and registered trademarks are the properties of their respective owners.**
- **If there is any uncertainty or controversy, please refer to the final explanation of us.**
- **Please visit our website or contact your local service engineer for more information.**